

REFILLING INSTRUCTIONS FOR EPSON ARC CARTRIDGES

Refillable Epson™ compatible inkjet cartridges, please note these ink cartridges are supplied empty! we let you choose your own inks, they work with: dye ink, pigmented ink, solvent ink, and subliminal ink. Unlike the Original Epson™ cartridges the refillable cartridges do not have the ink sensor inside, the ink sensor can cause big problems when trying to refill the original Epson™ cartridges!

The refillable ink cartridges will automatically reset themselves when they are removed from the printer when the ink runs low an X or X's will show in your ink level monitor, remove all the cartridges from the printer, refill them as normal, replace them in the printer just like you would replace the Epson original inkjet cartridges the cartridges will then be reset to full again! You never need to run out of ink, as long as you keep the cartridges topped up they will print for ever!

The refillable cartridges for following printer models automatically reset themselves when the ink level drops to around 5% D78-D92-R265-R360-RX560-R800-R1800 you have no need to remove them from the printer to reset them!

Please note the refillable cartridges have been specially developed to run in printers manufactured before and after April 2007, they use the latest chip technology. Risk free money back one year guarantee! (please keep proof of purchase).

Below is a generic side view of our refillable ink cartridges, there are many chambers to eliminate air bubbles from the ink, there is a fine gauze ink filter to help prevent large ink particles blocking the printhead. Please note the ink cartridges have a spring loaded non return valve, this means there is no leakage when you remove the cartridge from the printer. The ink cartridges are supplied with comprehensive fitting instructions, we also have a F.A.Q's trouble shooting page for your convenience. (cartridges may vary in spec)

