

INSTRUCTIONS FOR HP 88 HP 10-11 HP 84-85 ARC REFILLABLE INKJET CARTRIDGES

Remove the coloured ink stoppers from the air and ink fill holes, fill the cartridges with ink through the ink fill hole and replace the coloured stopper, the small cartridges each hold 28ml of ink, the large 58ml of ink if you want to store the cartridges for use another time replace all the coloured stoppers. When you need to use the cartridges remove the stoppers from the air hole only this allows the ink to flow freely.

Every so often have a visual check on the cartridges to make sure they are full of ink, if you let them run out this will cause the ink heads to be depleted of ink, when this happens you will have to replace the ink heads which can turn out very expensive!

On the L7480 all in one printer sometimes in the ink level monitor it will show a ? mark usually on the black cartridge, ignore this error and carry on printing after a while open the cartridge carrier door flap after a minute, close the door flap, the black ink monitor should now show full again.

INSTRUCTIONS FOR HP 363 ARC REFILLABLE INKJET CARTRIDGES

All our HP 363 cartridges are fitted with the latest type of auto-reset chips and will fit all HP printers which accept this cartridge no matter when the printer was made. The cartridges will reset when the ink level reaches around 5%. We advise you not to overfill the cartridges or it can get messy! Just fill the smaller cartridges with 12ml of ink and the larger black with 33ml of ink, replace the rubber stoppers before you insert the cartridges into the printer. The cartridges are see through for your convenience. You do not have to remove the cartridge from the printer to refill, just top them up and keep printing they will auto reset by themselves. Save £££'s on your printing up to (90%) saving on OEM cartridges. Purchase our HP compatible inks and save even more money!

INSTRUCTIONS FOR HP 364 REFILLABLE INK CARTRIDGES

To setup the HP 364 cartridges first remove the orange protective covers, then use the chips off the original ink cartridges, just remove them with a sharp kraft knife, they have a sticky back and re-fitting to the refillable cartridges is very easy. Look on www.Youtube.com to view instructions type in your printer model IE HP364 and view a video of fitting instructions. Fill each cartridge with the correct colour ink and replace the coloured stopper. pull off the yellow tape this will let the ink flow. The cartridges are see through so when the ink is showing low top the cartridges while they are still in the printer (if possible) this helps avoid ink leaking from the ink outlet, if you remove the cartridges from the printer do not overfill them, replace the coloured stopper re-insert the cartridges into the printer.

INSTRUCTIONS FOR HP 940 REFILLABLE INK CARTRIDGES

You have to use the chips off the original ink cartridges just remove them with a sharp knife, they have a sticky back and replacement is very easy.

Remove the coloured ink stoppers from the air and ink fill holes, fill the cartridges with ink through the ink fill hole and replace the coloured stopper, the small cartridges each hold 28ml of ink, the large 58ml of ink if you want to store the cartridges for use another time replace all the coloured stoppers. When you need to use the cartridges remove the stoppers from the air hole only this allows the ink to flow freely.

Every so often have a visual check on the cartridges to make sure they are full of ink, if you let them run out this will cause the ink heads to be depleted of ink, when this happens you will have to replace the ink heads which can turn out very expensive!

For the refilling process we advise that you wear surgical gloves